

TECHNICAL NOTE # 209

RE: Multiple Map Monitor Installation
Date: November 09, 2000

Multiple Map Monitor has the capability to monitor up to eight (8) INTREPID MicroPoint sites on one computer.

Multiple Map Monitor must be installed in a separate folder for every site used. Each Multiple Map Monitor program should be assigned a different name to be related to the specific site. Example: Multiple Map Monitor Site A.exe. This will also create individual .ini files for proper operation. If desired, one could also install the Site Manager software in each folder. Again each one would need to be assigned a different name.

Desktop short cuts can be made but each file must be installed in the start up menu. If for any reason the computer goes off line, when restarted all maps will automatically come on line.

The maps should be opened from windows explorer. Once the first map has been opened, you would Alt – Tab back to explorer to open the next map or maps.

When each map is opened you must set the communication port that the map is routed to. You must also set any options and adjust any other parameter associated with each site map.

Once all the maps are open and configured any alarm that occurs will bring the map that has an alarm to the top or front.