

# Southwest Microwave Intrepid Integration

*Mirasys Video Management System has been integrated with the Southwest Microwave Intrepid intrusion detection system. Mirasys VMS supports Intrepid integration through configurable text data channel communication. The integration is based on Southwest Microwave IPP 2 Poll protocol SDK. Integration is provided using a selected set of alarm events.*

## Features

The integration supports the following sensor types by default:

- **MicroPoint 2 alarm events** – Cable and sub-cell, AUX-input, cable fault and tamper alarms.
- **MicroTrack 2 alarm events** – Cable and sub-cell, cable fault and tamper alarms.
- **AlarmInputModule 2 (AIM 2) alarm events** – Alarm input (0-7) and supervised input alarms.
- **Model 330 alarm events** – Tamper, Sensor, Path and Service alarms.

